

MAX STAR

MAX STAR

MAXSTAR APPLIANCE LIMITED

1/7, West Patel Nagar, Opposite Pillar No. - 205, New Delhi - 110008

Tel: 08882650660, 011-2588 5791; e-mail: customercare@maxstar.in; Website: www.maxstar.in

★

MAX STAR


Electric Kettle

CORAL

1.5 Ltr.

USER MANUAL

Please read this book carefully before using this appliance.



Thank you for choosing our products. It is just one of a complete range of cleverly Designed, safe and practical products which will help to make your life easier.

**Please read these instructions carefully to get the best results from this product.**

**SAFETY INSTRUCTIONS**

- This kettle is designed for domestic use only. No responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
- The kettle is designed for heating water only. Never put any other liquid into the kettle nor should it be used as another cooking appliance.
- Before inserting the main plug into the socket, check whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
- Do not operate the kettle with wet hands.
- Keep children away from the kettle which is either in heating or filled with hot water.
- Prevent from scaling water or steam.
- Pour away the very first water boiled with this kettle. Then it is ready for use.
- Do not touch any part of the kettle except the handle when the kettle is fully filled with boiling water.
- Pour out the boiling water, all at one time, so as to enable the temperature of the kettle to decline.
- Remove the plug from the wall socket in the following case:
  - after use
  - malfunction comes up
  - before cleaning
- When removing the plug from the wall socket, never pull on the power cord.
- Regularly clean and scour out the kettle. But do not immerse the kettle or power base in water. As it will damage the appliance.
- Do not expose the kettle to rain or moisture.
- To prevent damage to the power cord, do not let it pass over sharp corners or edges.
- Do not operate the kettle if the kettle or power cord shows any signs of damage.
- If the kettle has been dropped.
- If repairs are needed, please send the kettle to qualified personnel.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This kettle must only be used with the power base supplied.
- This appliance is recommended for household use only.

- When removing the plug from the wall socket, never pull on the power cord.
- Regularly clean and scour out the kettle. But do not immerse the kettle or power base in water. As it will damage the appliance.
- Do not expose the kettle to rain or moisture.
- To prevent damage to the power cord, do not let it pass over sharp corners or edges.
- Do not operate the kettle if the kettle or power cord shows any signs of damage.
- If repairs are needed, please send the kettle to qualified personnel.
- If this appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This kettle must only be used with the power base supplied.
- This appliance is recommended for household use only.

**OPERATION GUIDELINES**

**1. Filling water**

- The capacity of filled water is limited by the ultimate line graduated on the water level scale. It should not be higher than the max line, nor lower than the minimum line.
- On filling water, care should be taken to avoid water column flowing on the kettle's outside surface.

**2. Locating**

- Place the kettle on a stable flat surface.
- Never heat the kettle on any wet surface, do not allow water to penetrate the electrical parts inside the kettle.
- Do not position the kettle on or near hot surface or near open flames.

**3. Switching on**

- Insert the main plug on the power cord into the wall socket.
- Please take care that the power cord must be well located and can not be caught on by a passerby.
- Push the restoring switch on.
- The red indicator lamp brights. It indicates that the kettle is in heating.

**4. Boiling**

- The kettle is automatically switched off several seconds after the water is boiling.
- The red indicator lamp goes out as switch off.

**5. Restoring**

- After the kettle has switched off, it will take about 15 mins to cool down and the kettle can be switched on again by manual restoring.
- If the red indicator lamp still goes out after pushing the restoring switch, it may be the case that the temperature sensing controller is still in hot condition and time must be taken for re-operating the kettle.

**FEATURE**

- Immersed heating tube with a stainless steel plate under it.
- Water level scale in metric & English systems and limit marks.
- Three levels of appliance protection.
  - Temperature sensing controller-automatic switch-off when water is boiling.
  - Dry boiling protector-boil-dry safety cut off
  - Thermal fuse cut off the circuit if dry boiling protector fails.

**TECHNICAL SPECIFICATION**

Capacity : 1.5L

Model : CORAL EK-02

RATING : 230V/50HZ

POWER : 350-1500W


S.NO : EK021706000001

★

MAX STAR

Electric Kettle

CORAL



RATING : 230V/50HZ

POWER : 350-1500W

WARRANTY CARD

WARRANTY

(As per terms and conditions overleaf)

Name of Purchaser : \_\_\_\_\_

Address : \_\_\_\_\_

Phone No. / Residence : \_\_\_\_\_

Office : \_\_\_\_\_

Product Sl. No. : \_\_\_\_\_

Date Of Purchase : \_\_\_\_\_

Customer's Signature

Dealer's Stamp & Signature

MAXSTAR APPLIANCE LIMITED

1/7, West Patel Nagar, Opposite Pillar No. - 205, New Delhi - 110008

Tel: 08882650660, 011-2588 5791; e-mail: customercare@maxstar.in; Website: www.maxstar.in

Please preserve the Warranty Card and Cash Memo and ensure that they are duly stamped and signed by the Company's dealer. The Warranty Card or a Cash Memo which is not stamped and signed by the dealer will be treated as invalid.

Max Star product that you have bought is of excellent quality and construction. However we will correct, free of charge any defects in material or workmanship for a period of one year\* (the Warranty period) from date of purchase subject to the terms and conditions.

**TERMS & CONDITIONS OF WARRANTY**

- Max Star products are warranted solely against poor workmanship, manufacturing defect and use of faulty material only. Consequential liabilities will not be entertained. All Max Star products are designed for domestic usage only.
- In the event of a replacement of spares during the warranty period, this warranty card will be required along with the original tax invoice/ Cash Memo to process the claim. The Company will not entertain a claim with incomplete warranty details.
- This warranty is confined to the first purchaser of the product only & is not transferable.
- Repair or replacement of spares will be carried out through the Company's Authorized Service Centre or its Authorized Dealers.
- Repairs during warranty period shall be carried on "Carry In" basis, wherein, for services, the purchaser shall bring the product to the Company's Authorized Service Centre/ Authorized Dealer for warranty service along with Tax Invoice/ Cash Memo and Warranty Card. The warranty does not cover cost of transportation of product from the customer's place to the Company's Authorized Service Centre/ Authorized Dealer. However, in case the customer is located beyond the municipal limits of the jurisdiction of the Company's Authorized Service Centre/ Authorized Dealer, writes the Company's Authorized Service Centre/ Authorized Dealer to collect the product from his place for the purpose of servicing the product then all expenses incurred in collection and delivery back of the product, as well as the expenses incurred in connection with shipping of service personnel/ technicians towards to and for travel, conveyance and other incidentals etc. will be borne by the customer.
- In the event of repair/ replacement of any parts of the product, this warranty will be thereafter continue and remain in force only for the unexpired period of the warranty. Moreover, the time taken for repair/ replacement and in transit whether under the warranty or otherwise shall not be excluded from the warranty period. The customer shall have to pay a visit charge towards inspection, as applicable.
- The Company/ its Authorized Service Centre/ Authorized Dealer, reserves the right to retain any parts or components replaced at its/her discretion in the event of a defect noticed in the equipment during the warranty period. The company shall have exclusive right to replace the defective /unserviceable parts or components with the parts or components which may be new or refurbished.
- The warranty does not cover accessories external to the product.
- The warranty does not cover demonstration/ installation of the product purchased.
- In the event of any unforeseen circumstance, and spares not being available, the Company's prevailing depreciation rules will be binding on the purchaser to accept as a commercial solution in lieu of repairs.
- The warranty is issued at Delhi and Courts at Delhi shall have exclusive jurisdiction over matters covered or flowing from this warranty.
- The Company's obligation under this warranty shall be limited to repairing or providing replacement of parts, which are found to be defective.
- In the event of repair/ replacement of specific parts on which warranty is more or more than product warranty, the specific parts will be repaired/ replaced free of the cost but customer needs to pay service charges in such cases.

**THIS WARRANTY IS NOT APPLICABLE IN ANY OF THE FOLLOWING CASES:**

- The warranty card is not duly filled by the selling dealer.
- The completed warranty card is not presented to the service personnel at the time of repair.
- The product is not purchased from an Authorized MAX STAR dealer.
- The product is not installed, used and maintained according to instruction given in the instruction manual.
- Defect caused by improper use as determined by the company personnel.
- Installation/ repair work is carried out by persons/ agency other than Authorized by the company.
- The original serial number is removed, obliterated or altered from the product.
- Defects have been caused by reasons beyond control of the Company, like act of God, during transit to Service Centre or purchaser's residence, poor maintenance, damage to the product caused by insect/ rodents.
- The warranty does not apply to:
  - Surface coating, body aesthetics, plastic parts, neon lamps, bake light part, rubber/ neoprene parts, cord wire, push button & bulb and durable parts viz: shaft, bush etc.
  - Normal wear and tear of parts.
  - Damages resulting from accidents, mishandling, improper use or negligence on the part of customer and fluctuation in supply voltage.
  - Damages resulting due to usage of power supply other than specified 230 Volts AC 50 Hz, e.g. inverters, generator etc.
  - For humming noise generated due to usage of electronic fan regulators of any make.
  - Breakage of glass parts.
  - Heating elements/ rods for failure or breakage.
  - Failure of parts due to scale deposition.